

多美地坪
Newtome



超精细混凝土地坪

高速抛光机



地址：宁波市江北庄桥石材城 2 号
东青岛市香港中路 142 号
电话：13905746604
3003718666 1

前 言

承蒙购买 多美地坪 机械有限公司生产的石材研磨翻新设备，
谨在此表示感谢！

在石材研磨领域中，本公司生产的专业石材研磨机拥有自主的
多项专利技术，本产品填补了该领域的空白，为石材研磨翻新之利
器，可达快速、理想的翻新效果，自投放市场以来，历经市场检验，
深受国内外用户的好评。请在使用本产品之前，务必详细阅读本使
用手册，并正确了解该设备使用、安装等相关事宜。

在使用之前，为了客户的利益，请填写如下资料：

型号：_____

序号：_____

Prefact

Thank for purchasing the stone polishing machine. Produced by Hangzhou Lijun Mechanical and Electrical Equipment Co.,Ltd.

In the field of stone repolishing and renewing, the professional stone polishing machine patented technique.

The product supply the gap in the field. It is an edge tool for stone repolishing and renewing, and can quickly reach an ideal repolish result. It has undertaken the inspection of the market ever since it was put into the market, and got good appraisal from domestic and foreign customers.

Please carefully read the application with out fail and accurately understand about use and installation before starting to use the machine.

For the benefit of the client, please fill in the following information before use it.

Type: _____

Series NO: _____

目 录 Contents

一、名称示意图 Sketch map of the names

02

二、用途及特点 Purpose and features

03

三、安全须知 Safety notice

04

四、规格表 List of specifications

05

五、操作说明 Explanation for operation

06


六、搬运说明 Explanation for conveying

07

七、状况处理 Handling abnormal status

08

一、名称示意图 Sketch map of the names



二、用途及特点 Purpose and features

- 水泥耐磨地坪可进行高速抛光
 - 环氧地坪进行清洁脏污抛光
 - PVC地板进行清理
 - 石材地板进行抛光研磨保养可高效率施作并节省大量药水材料成本。
 - 木地板地面可抛光研磨
-
- Concrete wear-resisting floor high-speed polishing ,epoxy floor cleaning dirt and polishing ,PVC floor cleaning ,effects of polishing the stone floor care can be efficient and save a lot of drops the cost of materials ,wood floor polishing

三、安全须知 Safety notice

- 操作人员须穿戴防水绝缘工作鞋。
 - 使用前须完全检查电源是否破损、老化、若有破损、老化应立刻更换。
 - 电源线安装时，须使用与本机规定相符之电压，电压变化必须保证在规定电压的10%以内。
 - 施工现场禁止非操作人员接近或使用本机。
-
- The operation should wear water proofing insulated shoes.
 - Before use,carefully check whether the cable of the power source is disr-epair or aging.If it is broken or aging,it should be immediately replaced
 - When installing the power source cable,it should use the one that suit the voltage level as specified for the machine.The voltage variety should be within 10% of the regulated voltage.
 - People who is not operator is prohibited from closing the machine or using it.

四、规格表 List of specifications

品名 Name	高速抛光机 HIGH SPEED GRINDING & POLISHING MACHINE
型号 Model	GM-27A
动力 Power	7.5KW (10HP)
电压 Voltage	380V x 3P
转速 Rotation speed	0-1200rpm
电源线径 Power cord	4mm ²
工作直径 Working diameter	27"(686mm)
加重 Balance weight	15-30kg
工作效率 Work efficiency	1000-3000m ² /8小时
喷水电源 Water spray electric power source	20W 12DVC
水箱容量 Water tank capacity	10公升
变频器参数 Transducer	7.5KW或11KW
磨盘转数 Speed of grinding plate	1200
电线长度 Wire length	0
尺寸 Dimension	170*90*70
重量 Weight	162KGS

四、规格表 List of specifications

品名 Name	高速抛光机 HIGH SPEED GRINDING & POLISHING MACHINE
型号 Model	GM-27B
动力 Power	7.5KW (10HP)
电压 Voltage	220V x 1P or 3P
转速 Rotation speed	0-1200rpm
电源线径 Power cord	4mm ²
工作直径 Working diameter	27"(686mm)
加重 Balance weight	15-30kg
工作效率 Work efficiency	1000-3000m ² /8小时
喷水电源 Water spray electric power source	20W 12DVC
水箱容量 Water tank capacity	10公升
变频器参数 Transducer	7.5KW或11KW
磨盘转数 Speed of grinding plate	1200
电线长度 Wire length	0
尺寸 Dimension	170*90*70
重量 Weight	162KGS

五、操作说明 Explanation for operation

1. 垫子安装：先将手把调整至垂直拉动握把调整杆，把机器压下，使机器成45° 平放，放入垫子（27"），可先将垫子中间压实，扣上垫扣压入，再把机器放平。
2. 接上电源：注意电线使用必须符合规定参考规格表。
3. 开启电源：手把先扶住，把停止开关打开，启动开关打开，调整调速开关，注意面板提示，慢慢开启至一定转速即可。
4. 喷水：先将水箱装满水，适当按喷水开关保持湿润至干，再按湿润至干来回摇摆操作即可。
5. 观察：使用不同号的垫子，可产生不同亮度，但要注意不要触碰凹洞或尖锐处，会使垫子受损。
6. 停机：使用中垫子会渐渐减薄，应适当注意更换。

1. Mat installation :to adjust the handlebar to pull the handgrip vertical adjustment bar,pressing machines ,the machine into a 45° flat ,place mats (27") ,place mats (27") ,pads on the mat can first be compressed buckles withheld in ,then put the machine on flat.
2. Plug in the :note wire used must comply with a reference specification sheet.

3. Turn on power :support ,turn the stop switch on ,start switch ,adjust speed switch ,note Panel tips ,slowly open to a certain speed.
4. Water spray :fill the water tank with water ,kept moist by spraying water switch to appropriate .
5. Watch :using different number of mats ,can produce different brightness, but be careful not to touch the concave holes or sharp, damage to the mat .
6. Downtime :use mat thickness reduction ,due attention should be paid to replace.

六、搬运说明 Explanation for conveying

将把手放至前端，电线架放低垫子最好装上，以免损坏钩盘。

Put my hand to the front-end ,lower wire rack pads put on ,so as not to damage the hook plate.

七、状况处理 Handling abnormal status



高速抛光机

HIGH SPEED GRINDING
& POLISHING MACHINE

1. 若机器运转不正常，须立即停机切断电源，检查皮带是否松动或磨损，也可通知本公司售后服务部或当地经销商。
 2. 若机器有异声，须立即停机，切断电源，及时通知本公司售后服务部或当地经销商。
-
1. If the machine runs abnormally, immediately cut off the power source, check whether the strap becomes flexible or is worn and torn. You can also inform the postsale service department of our company or the local dealer.
 2. If exceptional sound comes out of the machine, immediately stop the machine and cut off the power source. Inform the postsales service department or the local dealer in time.